

# Traditional wallpaper paste

Traditional wallpaper paste - does not contain plastic.  
Made in Finland.

Suitable for light wallcoverings such as  
traditional wallpaper, cardboard or paper,  
and for various types of wall surfaces.

Ingredients: sodium carboxymethylcellulose, NaCMC.  
Storage in dry place.

200 g is sufficient for 5 rolls (about 20m<sup>2</sup>).  
Mixing: 200g powder / 5 litres water.  
Working temperature: over + 18°C.  
Tools: mixing bowl, paste brush.

Mix wallpaper powder with water and stir generously.  
Let it sit until all clumps are dissolved.

Paste is transparent, thick and smooth jelly when ready.  
Add water if needed. Use in 2-3 days.

It is recommended to prepare paste at least 3-6 hours before wallpapering.  
Mix the paste once more before use.

Apply evenly with a paste brush on the back of the wallpaper.

Let wallpaper soak according to the manufacture's instruction.

If the paste accidentally ends up on the pattern side of the wallpaper,  
dab it off quickly with a clean, dry cloth.

